

Spotty oven glove



Requirements:

- 1/2m spotty fabric
- 1 long quarter plain fabric
- 1/2m x 45" [heat resistant wadding](#)
- [Thread](#) for sewing
- Matching [quilting thread](#)

1. From the spotty fabric cut 2x strips 7" x 33" and 2x rectangles 7" x 8.5"
2. From the plain fabric cut 2x rectangles 7" x 8.5" (cut both horizontally from the bottom of the long quarter to ensure maximum length is left for the binding later)
3. Line up the fabrics with one spotty and one plain rectangle at each end of the long strips. Cut the rounded end using the circular template provided (figure 1).



Figure 1

4. Lay one long strip and 2 rectangles on the wadding and cut out one of each shape, cutting slightly oversize to account for any shrinkage during quilting (figure 2).




Figure 2

5. Tack or pin all the layers together. Each end pocket should have a spotty fabric on one side and a plain fabric on the other with wadding in between, and the long strip should have wadding between two spotty strips.

6. Quilt as desired using matching quilting thread. The oven glove pictured has a simple spiral design working from the outside in (figure 3). Trim the excess wadding to the edge of the fabric. The long part of the glove is quilted in the same pattern - ensure that the layers are basted together securely to prevent movement.



Figure 3

7. Cut 4 x 2.5" strips from the remaining plain fabric. Cut a 7" strip from one long strip, fold in half lengthwise and press. Butt the raw edges against the flat edge of the pocket piece and sew in place 1/4" from the edge. Fold the binding over to the rear side and whip stitch in place to finish the straight edge (figure 4). Repeat for the other pocket piece.



Figure 4

8. Sew together the 3 remaining 2.5" strips of plain fabric to create 1 long strip for the outer binding. Fold in half lengthwise and press.

9. Assemble all the parts of the oven glove and pin in place (figure 5). Pin the binding strip all the way round, raw edges together. Sew 1/4" from the edge all the way around leaving an approximately 7" gap between the two ends. You may find it easier to cut the binding on the bias for this step, although in the example glove it was cut straight - you will need extra fabric to cut on the bias.



Figure 5

10. Cut the two loose ends of binding so there is a 2.5" overlap. Unfold the ends and lay on top of each other, right sides together and pin. Sew across the diagonal line (figure 6) and trim the excess.



Figure 6

11. Pull the binding out straight and sew the binding to the oven glove across the gap, 1/4" from the edge.

12. Using the remaining 2.5" strip of plain fabric, fold both sides to the centre and press, then fold in half again and press. Sew two lines along the length of the strip, approximately 1/8" from each side, to create a narrow strap for hanging the oven glove up. Trim the strap to 5" in length.

13. Turn the binding folded edge to the other side of the oven glove and pin the strap to the centre back, with the raw edges tucked under the binding (figure 7).



Figure 7

14. Whip stitch the binding in place all the way around the oven glove to finish.

As far as we know there are no mistakes in this quilt pattern, however if you need any further help or have spotted an error, please let us know by contacting us on sales@peleennapatchworks.co.uk.

Circular template (ensure when printing that the zoom setting is set to 'none' for accurate size - should be 7 inches diameter):

